

Fine Scissors



**Straight  
Sharp/Blunt**

10 cm  
Cutting edge: 17 mm

**No. 14028-10**



**Curved  
Sharp/Blunt**

10 cm  
Cutting edge: 17 mm

**No. 14029-10**

Lexer-Baby



**Straight  
Blunt/Blunt**

10 cm  
Cutting edge: 16 mm

**No. 14078-10**



**Curved  
Blunt/Blunt**

10 cm  
Cutting edge: 16 mm

**No. 14079-10**