

Fine Scissors



**Straight
Sharp/Blunt**

10 cm
Cutting edge: 17 mm

No. 14028-10



**Curved
Sharp/Blunt**

10 cm
Cutting edge: 17 mm

No. 14029-10

Lexer-Baby



**Straight
Blunt/Blunt**

10 cm
Cutting edge: 16 mm

No. 14078-10



**Curved
Blunt/Blunt**

10 cm
Cutting edge: 16 mm

No. 14079-10