

Lister Scissors

Longer blunt blade prevents damaging tissue underneath skin without losing the cutting line.



**Angled to side
Blunt/Blunt**

14 cm
Cutting edge: 26 mm

No. 91413-14



**Angled to side
Blunt/Blunt**

18 cm
Cutting edge: 30 mm


No. 91413-18



**Angled to side
Blunt/Blunt**

20 cm
Cutting edge: 34 mm

No. 91413-20



**Curved
Sharp/Blunt**

14.5 cm
Cutting edge: 28 mm


No. 91409-15



**Straight
Blunt/Blunt**

17 cm
Cutting edge: 32 mm

No. 91410-17



**Curved
Blunt/Blunt**

17 cm
Cutting edge: 32 mm

No. 91411-17

80% of
actual size

